

The Venturi System can be horizontal or Vertical




Air flow Filter (G)



Airflow in

Water Flow Out



Venturi System



1.5hP
Pump

Pressure Gauge (A)
8-10 PSI



Non Return Valve (K)
(Direction)



Water Flow Direction



Venturi Pressure Adjust Valve (J)

Air + Ozone flow out

NT-UV87-TO Installation

