


# The Air Blower Instructions



## INSTALLATION

Only the qualified, licensed personnel can install pump and wiring.

### IMPORTANT ELECTRICAL


Electrical Contractors Please Note: All 220(110) volt 50Hz(60Hz) EMAUX pumps must be wired to the main power supply through an approved and correctly rated contractors.

- 1) The pump must be fixed out of the bathtub or pool either inside or outside the bathroom with good ventilation. it can be used for the water massage in bathing, the supply of oxygen in water farming and so on.
- 2) If fixed outdoors, the pump must be 30cm higher than the water level.
- 3) If fixed indoors, the pump must be below the water level with a stop-return valve fitted at the outlet.
- 4) The air pump can be fixed either horizontally or vertically. The outlet is higher than the inlet. If it is vertical.
- 5) Make sure the pump is firmly fixed.
- 6) Join the appointed pipe to the outlet of the pump with PVC glue.(it's better to use it within 24 hours after stuck.)
- 7) Screw the joint tight. Otherwise the air leak will result in the small quantity of airflow.

## CAUTION

- 1) Non-professional personnel, do not open the air pump.
- 2) Be sure the power is right to the data marked in the plate of the air pump.
- 3) Don't touch it when the pump is running, Otherwise, you may get burnt.

## PARTS OF WIND PUMP



| Key No. | Part No. | Description                 | Qty |
|---------|----------|-----------------------------|-----|
| 1       | 03011081 | Screw                       | 6   |
| 2       | 01271004 | Cover for AB                | 1   |
| 3       | 07101073 | Sponge for Cover            | 1   |
| 4       | 01091005 | Stop Move Washer            | 1   |
| 5       | 07101074 | Sponge Washer               | 1   |
| 6       | 04021056 | Motor 220-230V,50/60Hz/350W | 1   |
| 6       | 04021098 | Motor 220-230V,50/60Hz/450W | 1   |
| 6       | 04021099 | Motor 220-230V,50/60Hz/550W | 1   |
| 6       | 04021070 | Motor 110-120V,50/60Hz/350W | 1   |
| 6       | 04021096 | Motor 110-120V,50/60Hz/450W | 1   |
| 6       | 04021097 | Motor 110-120V,50/60Hz/550W | 1   |
| 7       | 04014024 | Earth Cable                 | 1   |
| 8       | 04015036 | Thermoplastic Cover         | 2   |
| 9       | 01091006 | Placement Lock for Motor    | 1   |
| 10      | 01271003 | Body                        | 1   |
| 11      | 03013013 | Nut                         | 6   |
| 12      | 04014013 | Lock for Cable              | 1   |
| 13      | 04013025 | Cable                       | 1   |