


SIGNATURE SLIDE



BEFORE YOU START

For fun and effective setup, prepare to get wet. Throw on your bathing suit, gather your setup materials and jump in!

REQUIRED TOOLS





KEY 1 WATER HOSE

IMPORTANT NOTE

Moving the slide requires more than one person. Lift to move, do not drag the Slide, as it will scratch and damage the product.

WARNING

One child at a time. Don't stand/dive from slide. Misuse leads to serious injury. Don't use if physically impaired. Look for people and objects below. Ages 3+ 70 lbs (32kg) weight limit. Adult supervision required at all times. For use in maximum 18 in. water depth. Failure to position slide in proper location could lead to serious injury or death.

DANGER





head first



ledge, landing

loog ni



of pool, landing

loog ni



No Slide outside of pool, landing on ledge





FOR USE IN-POOL

STEP 1: Carefully remove Slide from packaging, place near tanning ledge and grab your water hose.

STEP 2: Using the included key, remove the plug at the top of the Slide deck. Do not discard the removed plugs, you will use them again in Step 5.



STEP 3: Place the slide inside your pool on your tanning ledge. The slide will be buoyant to start.

STEP 4: Using a water hose, fill the Slide while making sure it remains in your desired location on the ledge. Once filled, repositioning could damage the Slide.


STEP 5: Once the Slide is filled completely, replace plug at the top of the slide deck.

STEP 6: Time to play! Take a photo, share it on social media and tag #LEDGELOUNGER. We care about all of our little Ledge Lounger lovers, so remember, adult supervision while using the Slide is required.

Alternate setup methods are not recommended. Please adhere to the guidelines outlined above to avoid scratching or damaging your Barstool.

RFMOVAL

STEP 1: Using the included key, remove the plug under the step closest to the floor and the plug at the top of the Slide deck.



STEP 2: The water will begin draining unassisted and the Slide will become more buoyant as the water level decreases.

STEP 3: Once the Slide is mostly empty, grab the front end and carefully tilt to further assist with water removal.

STEP 4: Carefully remove the Slide from the pool. If a small amount of water remains, remove the plug at the bottom of the slide and gently rotate until completely empty.

Alternate removal methods are not recommended. Please adhere to the guidelines outlined above to avoid scratching or damaging your Slide.

HELPFUL TIPS

Clean often to prevent calcium build up. You can extend the life of your fabric products by storing them in a clean, shaded place when not in use.

Always use caution when moving or rearranging your Ledge Lounger products to avoid scratching or damage.

If you need Umbrella spacers or additional plugs, contact us via the contact form on our website.

For more tips please visit ledgeloungers.com/faq

PRODUCT CARE

Your Ledge Lounger is made of ultra durable, high quality materials. It is designed for the pool environment and resistant to sun, weather, and the reasonable chemical levels of a well maintained pool. We encourage you to leave your Ledge Lounger in the pool even when not in use.

However, when adding shock or other highly concentrated chemicals to your pool, remove all Ledge Lounger products, and return to the pool only once chemical levels are back to normal.

In the event of a freeze, please remove your Ledge Lounger products from the water, drain, and store in a safe location.

CLEANING YOUR FUNITURE

Always use a soft bristle brush or cloth when cleaning your Ledge Lounger furniture. For routine cleaning, just use water.

For a deeper clean, remove from the pool and use a mild household cleaner or a Magic Eraser.

Depending on the calcium levels of your pool, you may notice a white powder like coating develop on your furniture. If this occurs, we recommend cleaning it with CLR Calcium, Lime and Rust Remover.