



1. Unscrew the top cover and remove it
2. Unscrew the three screw as the photo
3. Dis-connect the connection " red circle".
4. Remove the controller and Replace a new one.
5. Connect the "red circle " cable
6. Screw the 3 screws tight.
7. Place back the top cover